ZoneVu

ZVK-007 Keyboard

USERS MANUAL - ADDENDUM

6.1 SUPERVISOR LEVEL FEATURES

The **SUPERVISOR LEVEL** is a system management level provided to configure keyboard and system parameters.

The system cannot be operated in the normal manner associated with the three **USER LEVELS**.

Once logged onto the **SUPERVISOR LEVEL** the display will show

SUPERVISOR	CONFIGURATION
LEVEL	ESC TO LOG OFF

To view the configuration options available press the **MODE** key - with each press the display will show -

ESC TO LOG OFF	ZVR CONFIG	DIALUP CONTROL
PASSWORDS	ZVM CONFIG	
MODE ACCESS	CAMERA CONFIG	
KEYBOARD SET-UP	FEATURE ACCESS	

6.10 DIALUP CONTROL

Dialup Control allows a supervisor to directly control the the usage of Meyertech Dialup devices, such as the ZSI family, to make permanent connections.

The display will show

SUPERVISOR	**Dialup Ctrl**	**No.1**	**MAC:61**
LEVEL	**Esc To Exit**	**Site 1**	

The keyboard contains a phone directory, with 20 entries.

STEP 1 Use the **ACT** & **PIP** keys to move forward and backwards through the list.

INFO *The* **No.1** *will update to show the current position in the list*

STEP 2 Use the **MODE** key to select an action for the current position in the list

- Dial
- Hangup
- Hangup All
- Edit number

STEP 3 Press the **PROG** key to carry out the current action

Dial **-** Send a dial command for the current number in the list

Hangup **-** Send a hangup command for the current number in the list

Hangup All **-** Send a hangup command to all dialup devices

Edit number **-** Change the details for the current entry in the list

Editing numbers

Each entry in the phone list can hold two phone numbers, or a site number. If a site number is entered instead of a phone number, the internal phone list of the dialup device will be used to look up the actual phone number.

Each entry contains a **MAC** number, which is the address of the dialup device to be used.

STEP 1 Press the **PROG** with the *Edit number* option selected.

STEP 2 The display will show

Site or Number ?

[S] or [N]

Press **S** to program a site number.

Press **N** to program a telephone number

STEP 3 Enter a site number, or full telephone number.

INFO *If making an ISDN call, a second phone number can be entered to make a two channel call. If not required leave the second number blank.*

STEP 4 Enter the MAC number for the dialup device to be used